

Ipmitool

Christian Külker

2022-06-30

Contents

1	History	2
2	Install	2
3	Set DHCP	2
4	Reset the BMC	2
5	BMC Sensor List	3
6	Set The NAC Address	3
7	Activate SOL	4
8	Debug SOL	4
9	Raw Commands	4
10	Testing	4
11	Links	5

The command line tool `ipmitool` is used to interact with a **Board Management Controller** (`BMC`) via the **Intelligent Platform Management Interface** (`IPMI`). `IPMI` is an open standard for monitoring, logging and control of hardware that is implemented independent of the main `CPU` , `BIOS` , and `OS` via a side band access. On some platforms `IPMI` can also be used to manage hardware inventory information.

- `SDR` - Sensor Data Repository
- `SEL` - System Event Log
- `FRU` - Field Replaceable Unit

1 History

Version	Date	Notes
0.1.3	2022-06-30	Formatting, changes->history, shell->bash
0.1.2	2020-05-03	Debug SOL
0.1.1	2020-05-02	Set MAC address raw
0.1.0	2016-02-12	Initial release

2 Install

```
aptitude install ipmitool
```

When using, make sure some kernel modules are loaded.

```
1 ipmi_devintf
2 ipmi_msghandler
3 ipmi_poweroff
4 ipmi_si
5 ipmi_watchdog
```

3 Set DHCP

```
ipmitool lan set 1 ipsrc dhcp
```

4 Reset the BMC

```
ipmitool mc reset cold
```

Or

```
ipmitool mc reset warm
```

5 BMC Sensor List

If the **BMC** supports it (that depends on the **OEM**) sensors can be listed. Some sensors might be on the **BMC** SOC, but most likely this sensors are made available to the **BMC** by various methods. Usually the **OEM** defines if the value is in or out of specification. Some values are depending on the **CPU** **OEM**.

```
ipmitool -I open sdr list
ACPI State      | 0x01          | ok
LPC Reset       | 0x01          | ok
Chassis         | 0x01          | ok
BMC RST         | 0x00          | ok
CPU0PECI        | 42 degrees C  | ok
CPU1PECI        | 38 degrees C  | ok
+1.1V           | 1.11 Volts    | ok
+1.4V           | 1.41 Volts    | ok
+0.9V           | 0.91 Volts    | ok
+3.0V           | 2.98 Volts    | ok
+1.5V           | 1.51 Volts    | ok
+2.5V           | 2.42 Volts    | ok
CPU0VCCP        | 0.97 Volts    | ok
CPU1VCCP        | 0.96 Volts    | ok
DDRCPU0         | 0.75 Volts    | ok
DDRCPU1         | 0.74 Volts    | ok
+1.8VICH        | 1.79 Volts    | ok
+1.5VICH        | 1.55 Volts    | ok
```

6 Set The NAC Address

Setting the MAC address if the **BMC** can be done via the **OS**.

```
ipmitool lan set <channel> macaddr <macaddr>
```

Sometimes the MAC address can only be set by Vendor specific raw commands. Sometimes the **BMC** has 2 **LAN** interfaces. The number depends on the hardware and **BMC** firmware. The channel number needs usually to be specified.

```
ipmitool raw 0x0c 0x01 0x01 0xc2 0x00
ipmitool lan set 1 macaddr aa:bb:cc:dd:ee:ff
ipmitool lan print 1

ipmitool raw 0x0c 0x01 0x08 0xc2 0x01
ipmitool lan set 8 macaddr a0:42:3f:2c:61:a2
```

```
ipmitool lan print 8
```

7 Activate SOL

To activate the **Serial Console Over LAN** (SOL). If the OEM configured the BMC in a secure way, a **user** and **password** is needed. However, since this is usually not changed, it can be a security problem.

```
ipmitool -I lanplus -H $REMOTEHOST -U $USER -P $PASSWORD sol activate
ipmitool -I lanplus -H $REMOTEHOST -U $USER -P $PASSWORD -v sol info
```

8 Debug SOL

To debug the setup of **Serial Over Lan** (SOL) add the **-v** option to enable verbose output and in some case set the privilege level explicit with the **-L** option.

```
ipmitool -v -L USER -I lanplus -H 172.20.50.102 -U admin -P admin sol
↪ activate
```

If his does not help use **namp** . See [ipmitool Fails with Authentication Issues](#)

9 Raw Commands

Sometimes the OEM implements undocumented features into the BMC firmware that can be reach via the **raw** option. As this commands are not standard it depends on the BMC what the out come will be. This is just an example.

```
ipmitool raw 0x36 0xc
```

10 Testing

Some OEMs implement meaningful self tests. However dummy self tests that always passes have been seen in the wild.

```
ipmitool mc selftest
Selftest: passed
```

11 Links

- [ipmitool source](#)
- [IPMI v2.0 Rev 1.1](#)